## **Dreamdock Trouble shooting Guide**

<u>Important Note</u>: For any unusual problem, system reset your radio as explained on page 42 of the Instruction book. An electronic copy of the latest Troubleshooting Guide can be downloaded from

http://www.robertsts.com/scripts/prodList.asp?idmod=DreamDock&idCategory=175

Symptoms	Cause/cure (🛠)
<ol> <li>Radio cuts out. On alarm buzzer comes on instead of radio. (Please note - If the radio cannot find the alarm to radio station it will revert to buzzer.)</li> <li><u>http://www.ukdigitalradio.com/ad</u> <u>vice/toptips/</u></li> </ol>	<ul> <li>Make sure the aerial is uncoiled. Reposition the radio/aerial to get maximum signal strength.</li> <li>To see signal strength adjust the display mode to 'Signal strength' see page 11 –g. Signal strength.</li> <li>Check the digital radio (DAB) coverage in your area using the link – www.ukdigitalradio.com/coverage/search/default.asp</li> <li>The type of building and surroundings can seriously affect the DAB reception. Sizeable concrete and metal work in the building (e.g. Block of flats, shopping centre, near or under a bridge, thermal insulation with metal foil in the loft) can considerably reduce the signal strength.</li> <li>Under these circumstances, an outdoor aerial is required for the optimum reception.</li> </ul>
2. Cannot receive BBC Sports Extra, display shows "Not Available".	<ul> <li>This radio station is not transmitting all the time. Transmitting details can be found using following links.</li> <li><u>http://www.bbc.co.uk/5livesportsextra</u></li> <li>See Secondary services – DAB on page 7.</li> </ul>
3. Not all the stations showing in the list.	• Fully extend the aerial and perform "Finding new stations – DAB" as suggested on page 12.
4. Sound Quality???	Check the DRC value, should be set to '0' unless listening in a noisy environment. See page 14.
5. Not keeping correct time.	Regularly switch on in DAB mode or briefly disconnect the power.